



Energizer Selection Guide

Acres	Power	Joules	Squirrel	Raccoon	Horse	Cow	Pig	Sheep	Lama	Elk	Bear	Model
110V PLUG-IN												
Up to 1	Low Impedance	0.05	●	●								PW50
1 to 3	Low Impedance	0.10	●	●								PW100
1 to 5	Low Impedance	0.20	●	●								PW200
1 to 30	Low Impedance	0.30	●	●	●							PW300
1 to 50	Low Impedance	0.50	●	●	●	●						PW500
1 to 75	Low Impedance	0.75			●	●	●					PW750
1 to 100	Low Impedance	1.0			●	●	●					PW1000
1 to 150	<i>Ultra</i> Low Impedance	1.50			●	●	●					PW1500
1 to 200	<i>Ultra</i> Low Impedance	2.0			●	●	●	●	●			PW2000
1 to 300	<i>Ultra</i> Low Impedance	3.0			●	●	●	●	●	●		PW3000
1 to 600	<i>Ultra</i> Low Impedance	6.0			●	●	●	●	●	●	●	PW6000
1 to 900	<i>Ultra</i> Low Impedance	9.0			●	●	●	●	●	●	●	PW9000
1 to 1,200	<i>Ultra</i> Low Impedance	12.0			●	●	●	●	●	●	●	PW12000
1 to 1,800	<i>Ultra</i> Low Impedance	18.0				●	●	●	●	●	●	PW18000
1 to 2,400	<i>Ultra</i> Low Impedance	24.0				●	●	●	●	●	●	PW24000
12V BATTERY												
1 to 25	Low Impedance	0.25	●	●	●	●						PW250B
1 to 50	Low Impedance	0.50	●	●	●	●						PW500B
1 to 100	<i>Ultra</i> Low Impedance	1.0			●	●	●	●	●	●		PW1000B
1 to 200	<i>Ultra</i> Low Impedance	2.0			●	●	●	●	●	●	●	PW2000B
D-CELL /12V BATTERY												
1 to 35	Low Impedance	0.35	●	●	●	●	●	●	●	●	●	PW350B
1 to 35	Low Impedance	0.35	●	●	●	●	●	●	●	●	●	PW350B+
12V SOLAR												
1 to 25	Low Impedance	0.15			●	●	●	●				PW100S
1 to 50	<i>Ultra</i> Low Impedance	0.25			●	●	●	●	●	●	●	PW200S
1 to 100	<i>Ultra</i> Low Impedance	0.50			●	●	●	●	●	●	●	PW500S